

PL215 Swivel Mouse Keyboard Platform Switch Mousing Platform from Right to Left Side

- 1st - remove the mouse guards and WristMate from the mousing platform
 - 2nd - remove the WristMate from the keyboard platform
 - 3rd - insert an allen wrench into the screw on the top of the mousing platform
 - 4th - with a pliers loosen the nut under the keyboard platform
 - 5th - remove the washers
Be careful not to loose any of the mounting hardware washers. They will be in the following order once the nut has been removed:
 - (1)small black washer - holds all washers onto screw while still in platform, (2) large thin black washers, (1) large thick black washer and (1) large thin black washer
 - 6th - remove the screw and mousing platform
 - 7th - flip over the mousing platform
 - 8th - slide the screw through the platform and the set of washers
 - 9th - install the nut on the bottom of the screw (there won't be much screw visible - but it will attach)
 - 10th - insert the allen wrench into the screw on the top of the mousing platform
 - 11th - with the pliers tighten the nut - but do not over tighten
 - 12th - install the mouse guards and WristMate on the mousing platform
 - 13th - install the WristMate onto the keyboard platform
- ALL Done :)

Sounds like a lot of work....but only takes about 3 minutes to complete. Please feel free to contact our Customer Service Department if you have any problem or need additional information.