



PLLTSM Laptop Platform with Swivel Mouse-Below Platform

Switch Mousing Platform from Right to Left Side

1. Remove the mouse guards and palm rest from the mousing platform
2. Remove the palm rest from the keyboard platform
3. Insert an Allen wrench into the screw on the top of the mousing platform
4. With a pliers loosen the nut under the keyboard platform
5. Remove the washers
 - a. **Be careful not to lose any of the mounting hardware washers**
 - b. They will be in the following order once the nut has been removed:
 - (1) small black washer - holds all washers onto screw while still in platform
 - (2) large thin black washers
 - (1) large thick black washer
 - (1) large thin black washer
6. Remove the screw and mousing platform
7. Flip over the mousing platform
8. Slide the screw through the platform and the set of washers
9. Install the nut on the bottom of the screw
(there won't be much screw visible - but it will attach)
10. Insert the Allen wrench into the screw on the top of the mousing platform
11. With the pliers tighten the nut – careful not to over tighten
12. Install the mouse guards and palm rest on the mousing platform
13. Install the palm rest onto the keyboard platform



The switch requires little mechanical ability and takes only about three (3) minutes to complete. Please feel free to contact our Customer Service Department if you have any problem or need additional information.

ergonomic
solutions